



Read entire document before initial use to prevent damage to the cabinet.

IMPORTANT!

INITIAL STARTUP AND AFTER A POWER INTERRUPTION

1. Apply power to cabinet.
2. Operate cabinet to maximum downward position.
3. Once cabinet is all the way down hold down button for 4 seconds.

The Cabinet is now ready to operate.

Note: If door is open or removed, the safety switch will prevent cabinet's height from adjusting.