


# **OMNIKEY® WORKBENCH**

## **RELEASE NOTES**

Version 1.7.3

PLT-03819, Rev. A.0

April 2018



## Copyright

© 2018 HID Global Corporation/ASSA ABLOY AB. All rights reserved.

This document may not be reproduced, disseminated or republished in any form without the prior written permission of HID Global Corporation.

## Trademarks

HID GLOBAL, HID, the HID Brick logo, the Chain Design, and OMNIKEY are trademarks or registered trademarks of HID Global, ASSA ABLOY AB, or its affiliate(s) in the US and other countries and may not be used without permission. All other trademarks, service marks, and product or service names are trademarks or registered trademarks of their respective owners.

MIFARE, MIFARE Classic, MIFARE DESFire, MIFARE DESFire EV1, MIFARE PLUS and MIFARE Ultralight are registered trademarks of NXP B.V. and are used under license.

## Revision history

| Date       | Description      | Revision |
|------------|------------------|----------|
| April 2018 | Initial release. | A.0      |

## Contacts

For additional offices around the world, see [www.hidglobal.com/contact/corporate-offices](http://www.hidglobal.com/contact/corporate-offices)

### Americas and Corporate

611 Center Ridge Drive  
Austin, TX 78753  
USA  
Phone: 866 607 7339  
Fax: 949 732 2120

### Asia Pacific

19/F 625 King's Road  
North Point, Island East  
Hong Kong  
Phone: 852 3160 9833  
Fax: 852 3160 4809


### Europe, Middle East and Africa (EMEA)

Haverhill Business Park Phoenix Road  
Haverhill, Suffolk CB9 7AE  
England  
Phone: 44 (0) 1440 711 822  
Fax: 44 (0) 1440 714 840

### Brazil

Condomínio Business Center  
Av. Ermano Marchetti, 1435  
Galpão A2 - CEP 05038-001  
Lapa - São Paulo / SP  
Brazil  
Phone: +55 11 5514-7100

**HID Global Technical Support:** [www.hidglobal.com/support](http://www.hidglobal.com/support)



# Contents

|                                                          |          |
|----------------------------------------------------------|----------|
| <b>Section 1: Introduction</b>                           | <b>5</b> |
| 1.1 Upgrading HID OMNIKEY® Workbench to v1.7.3           | 5        |
| <b>Section 2: HID OMNIKEY Workbench key feature list</b> | <b>5</b> |
| 2.1 OMNIKEY 5027 device support.                         | 5        |
| 2.2 Configuration card initialization for OMNIKEY 5027.  | 5        |
| 2.3 Stability improvement and bug fixing                 | 5        |
| 2.3.1 Data pooling improvement.                          | 5        |
| 2.3.2 PnP Service configuration fixed                    | 5        |

This page is intentionally left blank.

# 1 Introduction

---

This document lists all features and fixes introduced with HID OMNIKEY Workbench release 1.7.3.

## 1.1 Upgrading HID OMNIKEY® Workbench to v1.7.3

All updates are available in the Drivers & Downloads section of the HID Global website.

## 2 HID OMNIKEY Workbench key feature list

---

This section highlights the major changes introduced in HID OMNIKEY Workbench 1.7.3.

### 2.1 OMNIKEY 5027 device support

HID OMNIKEY Workbench tool can fully configure OMNIKEY 5027 device and display basic diagnosis.

### 2.2 Configuration card initialization for OMNIKEY 5027

HID OMNIKEY Workbench tool can create configuration card for OMNIKEY 5027 on any MIFARE DESFire EV1 credential.

### 2.3 Stability improvement and bug fixing

#### 2.3.1 Data pooling improvement

Previous versions of HID OMNIKEY Workbench caused any AVR based OMNIKEY reader to constantly blink with it's LEDs while Diagnosis pane was selected. This behavior was caused by redundant data request. Version 1.7.3x introduced plenty of optimization which successfully removed this behavior.

#### 2.3.2 PnP Service configuration fixed

PnP service configuration from OS Settings tab now correctly applies after system reboot. Be advice that new configuration will not be visible in group policy editor as HID OMNIKEY Workbench changes PnP Service behavior through registry keys.

